

AS REQUIRED BY UNDERWRITERS LABORATORIES, INC.
 INSTALLATION INSTRUCTION FOR THE
 165,265 / 185,285

1. Cabinet is to be cut as indicated below.
2. Line the $\frac{3}{8}$ " gas service line up with the hole provided in burner box so that it will slide into place when the range is placed into the opening.
3. Place range in position and fasten down with wood screws. Four holes in top trim and four holes in front trim are provided for this purpose.

DIMENSION A

Model 165 & 265 = 16- $\frac{3}{8}$ "

Model 185 & 285 = 18- $\frac{1}{8}$ "

